


MODERN EMBER

Gatsby Fireplace Screen Instructions

Unpack all contents from the package. Next, begin by attaching one bracket leg (B) to the bottom side of the frame (A) using the two screws (C) and two nuts (D) provided. Repeat the same operation on the other side.



CAUTION: Keep this product clean by using a damp cloth. DO NOT use abrasive cleaners, as it will cause parts to tarnish or rust.

Don't forget to tag us!
#mantelsdirect #modernember

